



Fitting Instructions

TOWBAR DT152U
For Nissan Qashqai
2014-

MATERIALS

A	1	Cross Tube
B	1	Chassis Brace
C	1	Side Arm
D	1	Chassis Brace
E	1	Nut Strap
F	2	M10 x 35 x 1.5 Bolts, Lock Washers and Plain Washer
G	2	M10 x 25 x 1.5 Bolts, Lock Washers and Plain Washer
H	2	M10 x 35 x 1.5 Bolts, Lock Washers and Plain Washer
J	1	M10 x 35 x 1.5 Bolts, Lock Washers and Plain Washer
K	1	M10 x 35 x 1.5 Bolts, 2 x Plain Washers and Nyloc Nut
L	1	Bumper Foam Support Plate
ZE	1	Electrical Plate
ZN	1	Neck option

FITTING

1. Remove the bumper (wheel arch screws, tip screw, 2 bottom edge screws)
2. Remove the bumper beam, and foam block.
3. Remove AdBlue tank, if fitted. (Remove plastic cover, electrical connectors all pipes (self-sealing bayonet connections).
4. Loosely assemble Chassis Brace (B) to inside faces of Left-Hand Chassis rail using fasteners (F).
5. Loosely assemble Chassis Brace (D) to outside faces of Right-Hand Chassis rail using fasteners (G) and Nut Strap (E), which is located by inserting to the inside of the chassis rail.
6. Loosely assemble Side Arm © inside Right-Hand Chassis rail using fasteners (H), through holes in previously fitted Chassis Brace (D).
7. Loosely assembly the Cross Bar (A) into Left Hand Chassis rail and to Side Arm (C) using fasteners (J, K & L)
Tip: Hold Cross Bar (A) at 45 degrees (right hand down) while inserting into Left-Hand Chassis rail then rotate anti-clockwise into position.
8. For vehicle bumpers with two large silver panels across the bottom half:
 - a. Assemble the chosen Neck kit (ZN), and Fixed Electrical Plate (ZE – shown below) to Cross Bar (A) using the respective kit instructions.
 - b. Cut the bumper using the 'Bumper Cut 1' image as a guide.
9. For vehicle bumpers which have an all-black bottom half:
 - a. Assemble the chosen Neck kit (ZN), and Retractable Electrical Plate (ZE – included inside Neck Kit) to Cross Bar (A) using the respective kit instructions.
 - b. Cut the bumper using the 'Bumper Cut 2' image as a guide.
10. **Fully tighten all fasteners**
11. Refit the AdBlue tank, if removed in previous instruction.
12. Refit the bumper the foam block to the two studs on the rear panel and then refit the bumper.

Recommended torque settings:

Grade 8.8 bolts: M8 - 24Nm, M10 - 52 Nm, M12 - 80 Nm, M14 - 130 Nm, M16 - 200 Nm

Grade 10.9: M12 – 120Nm, M10 – 70Nm M8- 35Nm



